



No. ARTICLE	NUMERO DE PIECE	DESCRIPTION	QTE
1	CL7431025-G00	PANNEAU DE PARE SOLEIL	1
2	CL7431025-D00	PANNEAU DE PARE SOLEIL	1
3	K7431025BH	HARDWARE KIT INCLUDES:	1
4	-	PR9431011-C01	1
5	-	PR9431025-G01	1
6	-	PR9431025-D01	1
7	-	PR9431025-G02	1
8	-	PR9431025-D02	1
9	-	PR9431011-C03	1
10	-	PR9431025-C01	1
11	-	PR9431011-G02	1
12	-	PR9431011-D02	1
13	-	PR9431011-G03	1
14	-	PR9431011-D03	1
15	B-TP14-20X34S	TRUSS PHILIPS 1/4"-20NCX3/4"SS	31
16	B-LW14S	LOCK WASHER 1/4" SS	31
17	B-HN14-20S	HEX NUT 1/4-20NC	27
18	-	LF.INSERT STL 1/4"-20NC X.160	10
19	-	GROMMET 5/16" DI X 21/32" DE	1
20	-	GROMMET 5/8" DI X 1 1/8" DE	4
21	B-W14S	FLAT WASHER 1/4"	37
22	B-TP14-20X12S	TRUSS PHILIPS 1/4"-20NCX1/2" S	2
23	B-HB14-20XS	HEX. BOLT 1/4NC X 1	4

**TRUX ACCESSORIES**

TITLE:  
**SUN VISOR INTERNATIONAL  
 WORKSTAR & PROSTAR 08 & UP**

SIZE DWG. NO.  
**A TSUN-I1**

NAME	DATE	REV	DATE
DRAWN BY P.W.	14-06-2007	PH1	-

SCALE: 1:9      WEIGHT: LBS      SHEET: 1 OF 1

## INSTALLATION INSTRUCTIONS

- 1- REMOVE THE EXISTING SUN VISOR AND KEEP THE FASTENING HARDWARE.
- 2- INSTALL BRACKET #7 & 8 ONTO THE SUN VISOR AS ILLUSTRATED.
- 3- INSTALL THE BRACKETS #5 & 6 ONTO THE EXISTING HOLES OF THE TRUCK,  
(THE CENTRAL AND EACH OUTSIDE SUPPORT AS ILLUSTRATED) USING THE  
FASTENING HARDWARE FROM PREVIOUS VISOR.
- 4- TEMPORARILY INSTALL THE SUN VISOR ON THE BRACKRTS ATTACHED TO THE  
SUPPORT USING, THE SUPPLIED FASTENING HARDWARE.
- 5- USING THE SUN VISOR, MARK BRACKETS #7 & 8 HOLES ON THE CAB.
- 6- AT BOTH ENDS REMOVE DOOR GASCKETS AND PUSH THE SUN VISOR IN PLACE AND  
MARK HOLES IN DOOR FRAME.

### CAUTION

BEFORE DRILLING,  
IT IS SUGGESTED TO REMOVE SUN VISOR  
TO PREVENT DAMAGE

- 7- DRILL THE PREVIOUSLY MARKED OUT HOLES AT 25/64" (.390625") DIA.
- 8- INSERT THE WELL NUTS IN THE HOLES.

### CAUTION

MODIFICATION ON TRUCK HARNESS,  
MAY BE REQUIERED TO CONNECT SUN VISOR HARNESS.

- 9- INSTALL THE LIGHTS OF LEFT AND RIGHT-HAND SIDE, AS WELL AS THE GROMMETS  
WHICH PROTECT WIRES.
- 10- MAKE THE CONNECTION OF THE LIGHTS AND DIRECT WIRE TOWARDS THE CENTER.
- 11- TEMPORARILY INSTALL THE SUN VISOR USING THE FASTENING HARDWARE, BUT  
DON'T COMPLETELY TIGHTEN FOR EASIER ADJUSTMENT.
- 12- INSTALL AND CONNECT THE CENTRAL LIGHT TO THE OTHERS.
- 13- INSTALL THE WIRE COVERS FROM OUTSIDE TO CENTER (#13, 14 & 11, 12) FINISH BY  
THE CENTRAL WIRE COVER (#10).
- 14- PASS THE CONNECTOR TROUGH THE GROMMET OF THE CENTRAL WIRE COVER AND  
CONNECT IT TO THE HARNESS ON THE TRUCK.
- 15- FINALLY TIGHTEN ALL BOLTS AND SCREWS FERMALY.

ENJOY.



<b>TRUX ACCESSORIES</b>			
TITLE: SUN VISOR INTERNATIONAL WORKSTAR & PROSTAR 08 & UP			
SIZE	DWG. NO. <b>A TSUN-I1</b>		
DRAWN BY	P.W.	DATE 14-06-2007	REV <b>PH1</b>
SCALE: 1:24	WEIGHT: LBS	DATE -	
SCALE: 1:24		WEIGHT: LBS	SHEET: 1 OF 1